



# FREEDOM 2

WITH SPEEDFIT

USER GUIDE

ENGLISH

## WELCOME

In The Box .....	2
Charging / Battery Status .....	3
Pairing .....	5
Finding Your Perfect Fit.....	7
Finding the Right Sized Fin/Tip Combo .....	7
Over-Ear Fit .....	8
Under-Ear Fit .....	9
SpeedFit Cord Management .....	10
Shirt Clip .....	11

## DETAILED INSTRUCTIONS

Button Functionality.....	12
The Jaybird App .....	15
Multipoint - Connection to multiple devices .....	17
ShareMe .....	18
Smartwatches .....	20
Troubleshooting .....	21
Specifications .....	22
Warranty, Warnings & Safety .....	23

WELCOME



**THANKS FOR PURCHASING  
JAYBIRD FREEDOM 2. WE BRING  
MUSIC WHERE YOU SWEAT.**

For detailed video instructions please visit [jaybirdsport.com/support/](https://jaybirdsport.com/support/)

Please refer to the safety warnings for important product safety information prior to installation or use of the product.


# IN THE BOX

- 1. FREEDOM 2 Bluetooth Headphones
- 2. Charging Clip / Battery Pack
- 3. USB Charging Cable
- 4. 4 Pairs Silicone Tip / Fin Combos
- 5. Shirt Clip
- 6. Carry Pouch



# CHARGING/BATTERY STATUS

We recommend you charge your buds through any 5V 500mA USB power source. Wall/car adapters/chargers that supply more than 5.5 Volt will damage your Jaybird buds and should not be used.




**A** Take your included charge clip and USB cable and plug it into a USB power source.


**B** The red LED will show when charging, and will turn to green when fully charged.

**2.5 hours** charging gives **4 hours** of playtime.

**20 mins** charging gives **1 hour** of play time.



# CHARGING/BATTERY STATUS




When not playing music, pressing **Volume +** or **Volume -** will announce the battery level.\*


The LED will indicate a single green flash for more than 10% battery remaining and a single red flash when below 10%.

Your phone and the MySound App will also indicate battery status.

\*Standby Mode: Powered and not playing music or on a phone call.




# PAIRING




**A** On your phone/music device, turn Bluetooth® on and ensure it is actively searching for Bluetooth devices.

**B** With your FREEDOM 2 turned off, press and hold the **Power Button** until you see the LED flashing red/green. A voice prompt will say “**SEARCHING FOR YOUR MUSIC DEVICE**”




# PAIRING



**C** Select “Jaybird FREEDOM 2” in the list of discovered devices.

**D** FREEDOM 2 voice prompt will say: **“HEADPHONES CONNECTED”**.  
You are now ready to listen to your music



**If the pairing is not successful**, switch off your buds by pressing the **Power Button** until you hear **“POWER OFF”** and repeat the steps outlined above.


**NOTE:** When you turn your FREEDOM 2 buds on for the first time or after a reset, they will be in pairing mode.




# FINDING YOUR PERFECT FIT

## FINDING THE RIGHT SIZED FIN/TIP COMBO


**A** With the medium-sized fin/tip combo attached, place your buds firmly within your ear while in the under-ear position. The inline remote should be on the right side.




**B** If your buds are not comfortable, or feel loose, try alternative sized fin/tip combos. **Be patient, it may take some time to get the perfect fit.**



**C** Slightly pinch the eartip with your index finger and thumb. This helps create suction for a better hold.






**D** Once you are happy with the fit, you are good to go.



# FINDING YOUR PERFECT FIT

## UNDER-EAR FIT




The fin/tip combo is installed so the point of the fin is above the headphones and cable. When in the ear, the cable comes straight down towards the bottom of the ear and the point of the fin is nestled in your ear.



# FINDING YOUR PERFECT FIT

## OVER-EAR FIT


The fin/tip combo is installed so the point of the fin is above the headphones and pointing at the cable. When the ear, the cable goes towards the front of the ear and wraps up and over the ear, then back down at the back of the ear. This ensures the weight of the cable is being supported by your ears and provides the most secure fit.



# FINDING YOUR PERFECT FIT

## SPEEDFIT CORD MANAGEMENT

Adjust the SpeedFit cord clips to tighten the cables and secure it against the back of your neck. This ensures the cable doesn't bounce when you're active which can pull the headphones out of your ears.





# FINDING YOUR PERFECT FIT

## SHIRT CLIP

Use the included Shirt clip To secure your FREEDOM 2 buds to the back of your shirt.

Long side of the clip on the outside of the shirt.




WORKS WITH SPEEDFIT  
CORD CLIPS

# DETAILED INSTRUCTIONS

## BUTTON FUNCTIONALITY

 4 SEC PRESS



 ON/OFF


To turn **FREEDOM 2** on or off, press and hold the **Power Button** for about 4 seconds. A voice prompt will say "**POWER ON**" or "**POWER OFF**".



# DETAILED INSTRUCTIONS

● SHORT PRESS   ● 1 SEC PRESS

## PLAYING MUSIC



- VOLUME +   ● SKIP FORWARD
- PLAY / PAUSE   ● VOICE COMMANDS
- VOLUME -   ● SKIP BACKWARD

**Play or pause**, a song or video with a short press and release of the **Power Button**.

**To skip a song**, press the **Vol. +** button for 1 second.

**To go backwards**, press the **Vol. -** button for 1 second.


**To change the volume + or -**, short press the **Vol. +** or **Vol. -** button

**To activate voice commands**, (Siri or Google Now), press the **Power Button** for 1 second.

# DETAILED INSTRUCTIONS

● SHORT PRESS   ● 1 SEC PRESS   ●● DOUBLE PRESS

## PHONE CALLS



● SWITCH A CALL

● ACCEPT A CALL   ● DECLINE A CALL   ●● REDIAL

● MUTE / UNMUTE

**Accept a phone call**, with a short press of the **Power Button**.

**To decline a phone call**, press the **Power Button** for 1 second.

**To mute or unmute**, a call press the **Vol. -** button for 1 second.

**To redial**, a phone number you can double press the **Power Button**.\*

**To switch a call** from your phone speaker to your FREEDOM 2 buds short press the **Vol. +** button.

\*Standby Mode: Powered and not playing music or on a phone call.




# DETAILED INSTRUCTIONS

## THE JAYBIRD APP

The Jaybird App lets you customize the sound profile on your FREEDOM 2 buds.



Your new sound settings are saved right on your buds, so you can take your custom sound with you no matter where you go with any device you use.



# DETAILED INSTRUCTIONS

## THE JAYBIRD APP

**NOTE:** The Jaybird app works with **Jaybird Run, X3, Freedom** and **Freedom 2**. Other manufacturers and older Jaybird buds are not supported.

Adding additional bass to your sound profile through the **Jaybird app** will reduce play time.

### SOUND

Customize your sound settings. Changes are saved to your FREEDOM 2 buds.

### MUSIC

Indicates if music is playing on your device.

### DISCOVER

Discover presets from athletes and other users.

### SAVE


Save your new preset to your dashboard for easy access to all your favorite sound settings.

### HISTORY

Track through a history of your changes.

### DEVICE

See your connected device and battery status.




# DETAILED INSTRUCTIONS

## MULTIPOINT - CONNECTION TO MULTIPLE DEVICES

Multipoint allows you to be connected to two devices simultaneously. You can for instance be connected to your laptop and your mobile phone. While listening to music on your laptop you will be able to accept an incoming call on your phone.

- 1** Ensure your FREEDOM 2 buds are paired and connected to both devices. Follow pairing instructions on page 5-6.
- 2** Make sure that only the two devices you want to connect to are turned on and in proximity.


Your FREEDOM 2 can remember up to eight paired Bluetooth® devices and can be actively connected two devices at a time.




# DETAILED INSTRUCTIONS

## SHARE ME

The ShareMe feature allows you to share the music you are listening to with another pair of FREEDM 2 buds.



**A** Power on both pairs of FREEDOM 2 buds.




**B** Only connect one device to your music device. Ensure the second device is not connected to any Bluetooth device.


# DETAILED INSTRUCTIONS

## SHARE ME

The ShareMe feature allows you to share the music you are listening to with another pair of FREEDOM 2 buds.



- C** Press and hold '**VOL +**' on the connected buds, while you press and hold the '**VOL -**' on the second buds until the LEDs on both buds are flashing red/green.




- D** Both buds will be connected when the LEDs stop flashing and you will hear 'Headphones Connected'. Play some music and enjoy the shared experience.

# DETAILED INSTRUCTIONS


## SMARTWATCHES

With the right smartwatch you can leave your phone at home. Just sync music to your smartwatch and pair FREEDOM 2 to your smartwatch. Use your smartwatch user manual for instructions on how to pair a Bluetooth device.


Apple WatchOS



Samsung Tizen




Android Wear



# TROUBLESHOOTING


If your buds are not responding, connect the charge clip and USB cable to a power source. This will turn your buds off and perform a soft reset.

If this does not resolve your problem we recommend to reset your buds to their original factory Settings.



**NOTE:** Once your buds have been reset you will have to pair it again to your devices. Select **“FORGET”** or **“REMOVE”** Jaybird FREEDOM 2 from your device’s Bluetooth menu. Follow the pairing instructions on page 5-6 to repair your devices.

# SPECIFICATIONS

Bluetooth Version	4.1, Multipoint
Codec	AAC, SBC, Modified SBC
Profile	Handsfree, Headset, A2DP, AVCRP, SPP
Effective Range	10 meters (30 feet)
Play Time	4 Hrs + additional 4 Hrs with included charging clip*
Standby Time	110 Hrs*
Power	Bluetooth headset: 5.0V  , 0.5A
Charging Time	2.5 Hrs
Quick Charge	20 Min = 1 Hr play time
Dimensions	23.4 x 22.4 mm x 6.2 mm
Weight	Approx 15.15 g

\*Play time and standby time may vary due to usage conditions. Adding additional bass to your sound profile through the MySound app will reduce play time.



# WARRANTY, WARNINGS & SAFETY

Full warranty, care & maintenance details at:  
[jaybirdsport.com/warranty](http://jaybirdsport.com/warranty) +1.866.244.3399

**WARNING:** Due to the isolating characteristics of these headphones do not use while driving, riding a bike or where vehicular traffic is present, or in any other activity where failure to hear surrounding sounds could be dangerous. Use of these headphones at excessive volumes may cause permanent hearing damage. Always turn the volume down before use. Take caution in regards to inserting objects into ear canal, use at own risk. Do not wear the device while it is connected to a power source driven from main 110V or 220V lines.

Copyright 2016 Jaybird, LLC. All rights reserved. Jaybird, and the Jaybird logo are trademarks of Jaybird, LLC. Bluetooth is a trademark owned by Bluetooth SIG, Inc. USA, and licensed to Jaybird, LLC. iPhone, iPad and iPod are trademarks of Apple, Inc., registered in the US and other countries and App Store is a service mark of Apple Inc. All other trademarks are the property of their respective owners. Android is a trademark of Google Inc. in the United States and other countries. Manufactured under Freebit patent numbers EP2177045, US8630436, US8976995 and corresponding international patents. Assembled in Malaysia.

## EARTIP CLEANING

Keeping your Jaybird Buds eartips clean is essential for safe, hygienic use.

**IMPORTANT:** DO NOT attempt to clean the eartips without first removing them from the headphones. Getting the delicate circuitry inside your Jaybird Buds wet may cause permanent damage.

1. Firmly grip the eartip with one hand and the earphone with the other. Carefully remove the eartip from the bud.
2. Use warm water and mild soap on a damp cloth to remove dirt and earwax from the eartip. Do NOT use harsh cleaning agents.
3. Rinse and completely dry your eartip before placing them back on your buds.
4. Carefully push the eartips back onto the buds.



## LISTEN RESPONSIBLY

Avoid excessive volume levels and prolonged periods of listening. Prolonged listening at excessive volume levels may cause permanent hearing disability.

Do not use around road traffic.

## CARE AND MAINTENANCE

Clean eartips regularly of dirt and wax buildup. To clean, remove eartips from earbuds, then gently wipe away dust and oil with a dry cloth, and/or use warm water and mild soap to remove buildup. Rinse and completely dry before reattaching.

Before charging, ensure earbuds are completely dry of sweat and water.

Video instructions at [jaybirdsport.com](https://www.jaybirdsport.com)