



WELCOME


| In The Box | 2 |
|---|----|
| Charging / Battery Status | 3 |
| Pairing | 5 |
| Finding Your Perfect Fit | 7 |
| Choosing Your Setup | 7 |
| Fit for Sport Use | 8 |
| Fit for Casual Use | 11 |
| DETAILED INSTRUCTIONS | |
| Button Functionality | 14 |
| The MySound App | 17 |
| Multipoint - Connection to multiple devices | 19 |
| ShareMe | 20 |
| Smartwatches | 22 |
| Troubleshooting | 23 |
| Specifications | 24 |
| Warranty, Warnings & Safety | 25 |


WELCOME

THANKS FOR PURCHASING JAYBIRD X3. WE BRING MUSIC WHERE YOU SWEAT.

For detailed video instructions please visit javybirdsport.com/support/

Please refer to the safety warnings for important product safety information prior to installation or use of the product.













Carry Pouch



 $Comply^{TM}$ Isolation Ear Tips (S, M, L)










Shirt Clip




CHARGING/BATTERY STATUS

We recommend you charge your buds through any 5V 500mA USB power source. Wall/car adapters/chargers that supply more than 5.5 Volt will damage your Jaybird buds and should not be used.




2.5 hours charging gives8 hours of playtime.


20 mins charging gives1 hour of play time.




CHARGING/BATTERY STATUS



PAIRING



PAIRING



CHOOSING YOUR SETUP BASED ON USE

We recommend choosing a fit based on how you plan to use your Jaybird X3.










1. SET UP YOUR FINS











Place your X3 over your ear with the inline remote on your left side.


2. FINDING THE RIGHT SIZED TIPS AND FINS









B If your buds are not comfortable, or feel loose, try alternative sized tips and/or fins. You can also try the Comply[™] foam tips or remove the fins completely. Be patient, it may take some time to get the perfect fit.




Once you are happy with the fit, move onto step 3.





If you intend to use Jaybird X3 for casual use, we recommend the under-ear setup.




1. FINDING THE RIGHT SIZED TIPS AND FINS



With the medium-sized tips and fins attached, place your buds firmly within your ear while in the under-ear position. The inline remote should be on the right side.

B If your buds are not comfortable, or feel loose, try alternative sized tips and/or fins. You can also try the Comply™ foam tips or remove the fins completely. Be patient, it may take some time to get the perfect fit.

Once you are happy with the fit, you are good to go.




LEFT

RIGHT

2. SHIRT CLIP

Use the included Shirt clip To secure your X3 buds to the back of your shirt.


Long side of the clip on the outside of the shirt.



NOER-EP


4 SEC PRESS

BUTTON FUNCTIONALITY




SHORT PRESS
1 SEC PRESS

PLAYING MUSIC



DETAILED INSTRUCTIONS • SHORT PRESS • 1 SEC PRESS • DOUBLE PRESS

PHONE CALLS



^{*}Standby Mode: Powered and not playing music or on a phone call.


THE MYSOUND APP


MySound lets you customize the sound profile on your X3 buds.





Your new sound settings are saved right on your buds, so you can take your custom sound with you no matter where you go with any device you use.






MULTIPOINT - CONNECTION TO MULTIPLE DEVICES

Multipoint allows you to be connected to two devices simultaneously. You can for instance be connected to your laptop and your mobile phone. While listening to music on your laptop you will be able to accept an incoming call on your phone.


- Ensure your X3 buds are paired and connected to both devices. Follow pairing instructions on page 5-6.
- Make sure that only the two devices you want to connect to are turned on and in proximity.

Your X3 can remember up to eight paired Bluetooth® devices and can be actively connected two devices at a time.




SHARE ME

The ShareMe feature allows you to share the music you are listening to with another pair of X3 buds.








Only connect one device to your music device.


Ensure the second device is not connected to any Bluetooth device.

SHARE ME

The ShareMe feature allows you to share the music you are listening to with another pair of X3 buds.








Both buds will be connected when the LEDs stop flashing and you will hear 'Headphones Connected'. Play some music and enjoy the shared experience.

SMARTWATCHES


With the right smartwatch you can leave your phone at home. Just sync music to your smartwatch and pair X3 to your smartwatch. Use your smartwatch user manual for instructions on how to pair a Bluetooth device.



TROUBLESHOOTING

If your buds are not responding, connect the charge clip and USB cable to a power source. This will turn your buds off and perform a soft reset.

If this does not resolve your problem we recommend to reset your buds to their original factory Settings.



NOTE: Once your buds have been reset you will have to pair it again to your devices. Select "**FORGET**" or "**REMOVE**" Jaybird X3 from your device's Bluetooth menu. Follow the pairing instructions on page 5-6 to repair your devices.

SPECIFICATIONS

| Bluetooth Version | 4.1, Multipoint |
|-------------------|--|
| Codec | AAC, SBC, Modified SBC |
| Profile | Handsfree, Headset, A2DP, AVCRP, SPP |
| Effective Range | 10 meters (30 feet) |
| Play Time | 8 Hrs* |
| Standby Time | 110 Hrs* |
| Power | Bluetooth headset: 5.0V 🚃 , 0.5A |
| Charging Time | 2.5 Hrs |
| Quick Charge | 20 Min = 1 Hr play time |
| Dimensions | 27 x 24 mm earbud size, 490 mm cord length |
| Weight | Approx 13 g |
| | |

^{*}Play time and standby time may vary due to usage conditions. Adding additional bass to your sound profile through the MySound app will reduce play time.

WARRANTY, WARNINGS & SAFETY

Full warranty, care & maintenance details at: jaybirdsport.com/warranty +1.866.244.3399

WARNING: Due to the isolating characteristics of these headphones do not use while driving, riding a bike or where vehicular traffic is present, or in any other activity where failure to hear surrounding sounds could be dangerous. Use of these headphones at excessive volumes may cause permanent hearing damage. Always turn the volume down before use. Take caution in regards to inserting objects into ear canal, use at own risk. Do not wear the device while it is connected to a power source driven from main 110V or 220V lines.

Copyright 2016 Jaybird, LLC. All rights reserved. Jaybird, and the Jaybird logo are trademarks of Jaybird, LLC. Bluetooth is a trademark owned by Bluetooth SIG, Inc. USA, and licensed to Jaybird, LLC. iPhone, iPad and iPod are trademarks of Apple, Inc., registered in the US and other countries and App Store is a service mark of Apple Inc. All other trademarks are the property of their respective owners. Android is a trademark of Google Inc. in the United States and other countries. Manufactured under Freebit patent numbers EP2177045, US8630436, US8976995 and corresponding international patents. Assembled in Malaysia.

EARTIP CLEANING

Keeping your Jaybird Buds eartips clean is essential for safe, hygienic use.

IMPORTANT: DO NOT attempt to clean the eartips without first removing them from the headphones. Getting the delicate circuitry inside your Jaybird Buds wet may cause permanent damage.

- 1. Firmly grip the eartip with one hand and the earphone with the other. Carefully remove the eartip from the bud.
- 2. Use warm water and mild soap on a damp cloth to remove dirt and earwax from the eartip. Do NOT use harsh cleaning agents.
- 3. Rinse and completely dry your eartip before placing them back on your buds.
- 4. Carefully push the eartips back onto the buds.



LISTEN RESPONSIBLY

Avoid excessive volume levels and prolonged periods of listening. Prolonged listening at excessive volume levels may cause permanent hearing disability.

Do not use around road traffic.

CARE AND MAINTENANCE

Clean eartips regularly of dirt and wax buildup. To clean, remove eartips from earbuds, then gently wipe away dust and oil with a dry cloth, and/or use warm water and mild soap to remove buildup. Rinse and completely dry before reattaching.

Before charging, ensure earbuds are completely dry of sweat and water.

Video instructions at jaybirdsport.com